



## Racing Lane Modification Instructions

### SETTING BACKSTROKE MARKER ON LANE

1. Lay Competitor® Racing lane on a flat surface.
2. Release all slack on the Take Up Reel, so the Blue Nylon spool is showing.
3. Locate set-screw on Take Up Reel Spool and loosen.
4. Remove cable from Spool. Note the way the cable is threaded so reattachment is done in the proper manner.
5. Taking the 30' cable provided – splice tip to tip using a small piece of packing tape. Tape the free end of the cable to the 30' length.
6. Find the position at which you wish to place the marker. Slowly slide the disks onto the 30' section.
7. Disconnect the splice and slide the marking disk onto the lane.
8. Reconnect splice and slide lanes back on to lane cable.
9. Reattach hardware and repeat at other end of lane.

A photograph of a swimmer in a pool, wearing a blue swim cap and goggles, splashing water. The swimmer is in the foreground, and the background shows the lane lines of the pool.

[www.competitorswim.com](http://www.competitorswim.com)  
**800-888-SWIM (7946)**