



## Racing Lane Modification Instructions

## TO SHORTEN THE OVERALL LENGTH OF THE LANE

- 1. Lay Competitor<sup>®</sup> Racing lane on a flat surface or pool deck.
- 2. Release all slack on the Take Up Reel, so Blue Nylon spool is showing.
- 3. Locate set-screw on Take Up Reel Spool and loosen.
- **4.** Remove cable from Spool. Note the way the cable is threaded so re-attachment is done in the proper manner.
- **5.** Locate the new point on the cable (allow 4-6 inches extra for attachment and slack).
- **6.** Remove all disks and donuts up to the point. Allow 4-6 inches exposed to attach Take Up Reel.
- 7. Cut cable with small bolt/wire cutters.
- **8.** Re-thread cable back onto Take Up Reel Spool. Remember to feed cable through the hole with no set screw first.
- 9. Tighten set screw firmly to complete modification.



©2013 Competitor Swim Products. All rights reserved.