




937-702



Part No.	Description	Qty.
622-118	7.5' Champion Seat/Back	2
631-020	Stand (Direct Bury)	4
516-058	3/8" x 1-1/2" SS Hex Bolt	10
516-028	3/8" SS Nylock Nut	10
516-023	3/8" SS Washer	20

- 1 Drill plastic out of the mounting holes on the stands and the seats using a 7/16" dia. drill bit.
- 2 Attach seats together with 3/8" x 1-1/2" SS hex bolts, washers and nuts and then mount stands to the seats with 3/8" x 1-1/2" SS hex bolts, washers and nuts.
- 3 Drill 4 holes (8"-10"Dia.) into the ground matching the spacing of the legs on the bench.
- 4 Support the bench in the holes with wood stakes.
- 5 Check the level and straightness of the bench and then fill the holes with concrete to within 2" of ground surface.

In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.

*Periodic check of bolt tightness recommended.*



**PREMIER POLYSTEEL**

The Best Commercial Outdoor Furniture Available. Period.

