



31" & 37" Electric Pace Clocks

Model Numbers: 200302 | 200303 | 200702 | 200703

Assembly Instructions – 31" & 37" Electric Pace Clocks

1. Remove the clock from the carton and lay flat.
2. Slide clock out of plastic bag.
3. The clock may be turned on and off only. There is no automatic reset. The second hand may be reset manually by opening the back cover plate and turning the small dial located on the motor housing.

The 31" Electric Pace Clock can be wall mounted or attached to our Roll-A-Way Stand for easy removal and storage.



PLEASE NOTE: COMPETITOR PACE CLOCK HANDS ARE SPECIFICALLY DESIGNED AND ENGINEERED FOR THE POOL ENVIRONMENT AND ARE FRAGILE!!!



www.competitorswim.com

1-800-888-SWIM




PLEASE NOTE: COMPETITOR PACE CLOCK HANDS ARE SPECIFICALLY DESIGNED AND ENGINEERED FOR THE POOL ENVIRONMENT AND ARE FRAGILE!!!


Assembly Instructions – Minute Hand

See our instructional video at www.competitorswim.com.

1. Align oval hole on minute hand with oval on shaft of motor and push minute hand on to shaft. **(Image A)**
2. Apply knurled nut on to threaded oblong shaft and gently tighten with pliers until snug. **(Image B)**



A



B

Assembly Instructions – Second Hand

1. The 31" Electric second hand is pre-mounted with a threaded fitting.
2. Line up the second hand with stem and tighten the second hand by turning clockwise.
3. Tighten until snug. **Do not overtighten as fitting will dislodge from hand.**
4. Turn motor on to make sure minute hand and second hand do not strike each other.
5. If they do strike each other upon passing then **gently** bend hands in opposite directions until clearance is achieved. Bend as close to the motor shaft as possible.