

Used Sling or Wicker frames Removal

Unfold the product and set the 2 locks on the Legs.

Set Product upside down on a table. See figure 1.

To remove the screws, hold firmly the Sling into the Plastic Structure, close to the screw you are removing. See figure 2.

Remove the 4 screws from the Back. See figure 3.

Remove the 4 screws from the Seat. See figure 4.




Figure 1



Figure 2




Figure 3




Figure 4

REVISIONS

Rev. No.	Description	Date	Revised By



**Those steps are only for the Sling version
(not the Java Wicker)**

After removing the Sling from the Plastic Structure set it up right (See *figure 5*), then remove the 2 top plugs on the used Sling Backrest and save those parts. See *figure 6*.

Be careful in identifying which part goes where : there is a Left and a Right. See *figure 7*.

Reposition those 2 parts on the Replacement Sling. See *figure 8*.

Position the Replacement Sling in the Plastic structure, and pay close attention to the position of those caps. They should fit in properly like shown on the picture. See *figure 9*.



Figure 5




Figure 6




Figure 7



Figure 8




Figure 9



Setting the Replacement Sling or Wicker Frame in

After positioning the Replacement Sling / Wicker into the Plastic Structure, keep the Chair up right. Hold tight the Sling / Wicker into the Plastic Structure close to the screw you are attaching. Start with the 2 top screws., then screw in the 2 lower ones. See figure 10.

Pay close attention to the 2 Top Caps position (only for the Sling version). See figure 11 (a & b).

After you are done with the 4 Backrest screws, flip the Chair upside down on a Table. See figure 12.

Hold tight the Sling / Wicker into the Plastic Structure close to the screw you are attaching. Put the 4 screws in : prefer one on each side before setting the second one. See figures 13.

